

Winter maintenance tips from KA Witt Construction

- ✓ Replace furnace filter.
- ✓ Inspect pressure and temperature valve on water heater.
- ✓ Readjust registers to rezone house for winter.
- ✓ Check for humidity levels in house and lower level to prevent excessive moisture.
- ✓ Clean faucet aerators and turn on infrequently used faucets.
- ✓ Put water in floor drains to maintain traps – water barrier.
- ✓ Inspect adjustable thresholds on exterior doors for proper adjustment.
- ✓ Clear air intakes and exhaust pipes, meters of snow.
- ✓ Remove excess snow from roof valleys to prevent roof dams.
- ✓ Continue running HRV – adjust humidity level with the outside temperature.